ACTIVATED CARBON TRANSFER OPERATION

MANDATORY PPE DURING THE TRANSFER OPERATION

SAFETY GOGGLES

FFP2 RESPIRATOR

PROTECTIVE GLOVES

ATEX PROTECTIVE CLOTHING

SAFETY BOOTS

SAFETY HELMET WITH CHIN STRAP

ATEX AREA

INSTRUCTIONS

1 BEFORE THE TRANSFER

- **Check the identity of the product.**
- **Check that the silo has sufficient capacity to receive the delivered quantity (< 35 t)**
- **Check the proper functioning of the filter cleaning system.**
- **Verify that the emergency safety shower is operational.**
- Connect the truck to the site grounding point.
- Direct rainwater to the plant drainage system.
- Check the silo fluidization air supply and temperature (< 40°C).

2 DURING THE TRANSFER

- **The unloading supervisor must be present at all times.**
- **Ensure that no one is on the silo roof and that the access door is closed.**
- Monitor the transfer operation continuously.
  (If any abnormality occurs: stop the operation immediately and notify your supervisor)

3 AFTER THE TRANSFER

- Disconnect the grounding strap and redirect the rainwater to the CUB circuit.
- Ensure the area is clean before leaving, and only depart after approval from the unloading supervisor.

IN CASE OF FIRE OR ACCIDENTAL SPILL

- Call the Control Room at **05.56.38.55.10**
- Remove contaminated clothing.
- Rinse the affected area with water.
- Inform site personnel and seek medical attention.

IN CASE OF AN ACCIDENTAL SPILL

If the spilled quantity is small, dilute it with plenty of water.

NO SMOKING OR VAPING

MORE INFORMATIONS
MOP, FDS, FSU...
Scan me!