

PSR TRANSFER OPERATION

MANDATORY PPE DURING THE TRANSFER OPERATION



**SAFETY
GOGGLES**



**FFP3
RESPIRATOR**



**PROTECTIVE
GLOVES**



**PROTECTIVE
SUIT**



**SAFETY
BOOTS**



**SAFETY
HELMET WITH
CHIN STRAP**



CONTAINS C.M.R. SUBSTANCES

INSTRUCTIONS

1 BEFORE THE TRANSFER

- **Verify that the emergency safety shower is operational.**
- Connect the truck to the site grounding point.
- Direct rainwater to the plant drainage system.
- A truck can be filled with 21-24 t, depending on the tanker.

2 DURING THE TRANSFER

- **The unloading supervisor must be present at all times.**
- When filling a compartment, **leave a second manhole partially open**
- Monitor the transfer operation continuously.
(If any abnormality occurs: stop the operation immediately and notify your supervisor)

3 AFTER THE TRANSFER

- Close all tank's manholes.
- Disconnect the grounding strap and redirect the rainwater to the CUB circuit.
- Ensure the area is clean before leaving, and only depart after approval from the unloading supervisor.



IN CASE OF FIRE OR ACCIDENTAL SPILL



- Call the Control Room at **05.56.38.55.10**
- Remove contaminated clothing.
- Rinse the affected area with water.
- Inform site personnel and seek medical attention.



IN CASE OF AN ACCIDENTAL SPILL

If the spilled quantity is small, dilute it with plenty of water.



**NO SMOKING OR
VAPING**



**MORE INFORMATION
MOP, FSU...**
Scan me!

