REFIOM TRANSFER OPERATION

MANDATORY PPE DURING THE TRANSFER OPERATION

SAFETY GOGGLES

FFP3 RESPIRATOR

PROTECTIVE GLOVES

PROTECTIVE SUIT

SAFETY BOOTS

SAFETY HELMET WITH CHIN STRAP

SAFETY HARNESS

CONTAINS C.M.R SUBSTANCES

INSTRUCTIONS

1 BEFORE THE TRANSFER

- **Establish the safety perimeter and restrict access.**
- **Ensure the truck is equipped with access equipment compliant with the standards.**
- **Verify that the emergency safety shower is operational.**
- **Do not exceed the maximum authorized truck load during filling.**
- Make sure the sleeve is properly positioned

2 DURING THE TRANSFER

- **The unloading supervisor must be present at all times.**
- **No one shall stand on the tanker during operations.**
- When filling one compartment, **all other manhole covers must remain closed.**
- Monitor the transfer operation continuously. (If any abnormality occurs: stop the operation immediately and notify your supervisor)

3 AFTER THE TRANSFER

- Close tank's manholes.
- Ensure the area is clean before leaving, and only depart after approval from the unloading supervisor.

IN CASE OF FIRE OR ACCIDENTAL SPILL

Call the Control Room at **05.57.35.16.90**

Remove contaminated clothing.

Rinse the affected area with water.

Inform site personnel and seek medical attention.

IN CASE OF AN ACCIDENTAL SPILL

If the spilled quantity is small, dilute it with plenty of water.

NO SMOKING OR VAPING

MORE INFORMATIONS MOP, FSU...

Scan me!