# REFIOM TRANSFER OPERATION

## MANDATORY PPE DURING THE TRANSFER OPERATION

SAFETY GOGGLES

FFP3 RESPIRATOR

PROTECTIVE GLOVES

PROTECTIVE SUIT

SAFETY BOOTS

SAFETY HELMET WITH CHIN STRAP

CONTAINS C.M.R SUBSTANCES

## INSTRUCTIONS

### 1 BEFORE THE TRANSFER

- **Ensure the truck is equipped with access equipment compliant with the standards.**
- **Verify that the emergency safety shower is operational.**
- **Do not exceed the maximum authorized truck load during filling.**
- Make sure the sleeve is properly positioned.

### 2 DURING THE TRANSFER

- **The unloading supervisor must be present at all times.**
- **No one shall stand on the tanker during operations.**
- When filling a compartment, **leave a second manhole partially open**
- Monitor the transfer operation continuously. (If any abnormality occurs: stop the operation immediately and notify your supervisor)

### 3 AFTER THE TRANSFER

- Close tank's manholes.
- Ensure the area is clean before leaving, and only depart after approval from the unloading supervisor.

## IN CASE OF FIRE OR ACCIDENTAL SPILL

PREMIER SECOURS

Call the Control Room at **05.56.38.55.10**

Remove contaminated clothing.

Rinse the affected area with water.

Inform site personnel and seek medical attention.

### IN CASE OF AN ACCIDENTAL SPILL

If the spilled quantity is small, dilute it with plenty of water.

NO SMOKING OR VAPING

MORE INFORMATIONS MOP, FSU...

Scan me!