CAUSTIC SODA TRANSFER OPERATION

MANDATORY PPE DURING THE TRANSFER OPERATION

SAFETY GOGGLES

FFP2 RESPIRATOR

PROTECTIVE GLOVES

CHEMICAL PROTECTIVE SUIT

SAFETY BOOTS

SAFETY HELMET WITH CHIN STRAP

CORROSIVE

INSTRUCTIONS

1 BEFORE THE TRANSFER

- **Check the identity of the product.**
- **Check that the delivered quantity does not exceed the tank capacity : 30 mS (< 46,55 t).**
- **Establish the safety perimeter and restrict access.**
- **Verify that the emergency safety shower is operational.**
- Park the vehicle within the retention area.

2 DURING THE TRANSFER

- **The unloading supervisor must be present at all times.**
- Monitor the transfer operation continuously.
  (If any abnormality occurs: stop the operation immediately and notify your supervisor)

3 AFTER THE TRANSFER

- Relieve the pressure from the tanker at the top by the driver.
- Disconnect and clean the hose.
- Ensure the area is clean before leaving, and only depart after approval from the unloading supervisor.

IN CASE OF FIRE OR ACCIDENTAL SPILL

PREMIER SECOURS

- Call the Control Room at **05.57.35.16.90**
- Remove contaminated clothing.
- Rinse the affected area with water.
- Inform site personnel and seek medical attention.

18

IN CASE OF AN ACCIDENTAL SPILL

If the spilled quantity is small, dilute it with plenty of water.

NO SMOKING OR VAPING

MORE INFORMATIONS
MOP, FDS, FSU...
Scan me!