

UREA TRANSFER OPERATION

MANDATORY PPE DURING THE TRANSFER OPERATION



SAFETY GOGGLES



P2 RESPIRATOR



SAFETY HELMET WITH CHIN STRAP



PROTECTIVE GLOVES



PROTECTIVE SUIT



SAFETY BOOTS

INSTRUCTIONS

1 BEFORE THE TRANSFER

- Check the identity of the product.
- Check that the delivered quantity does not exceed the tank capacity (< 40 t).
- Verify that the emergency safety shower is operational.
- Direct rainwater to the plant drainage system.
- Check the sump level in the urea room.
- Connect the ground terminal to the truck.

2 DURING THE TRANSFER

- The unloading supervisor must be present at all times.
- The offloading pressure must not exceed 1 bar.
- Monitor the transfer operation continuously.
(If any abnormality occurs: stop the operation immediately and notify your supervisor)

3 AFTER THE TRANSFER

- Disconnect the grounding strap and redirect the rainwater to the CUB circuit.
- Ensure the area is clean before leaving, and only depart after approval from the unloading supervisor.



IN CASE OF FIRE OR ACCIDENTAL SPILL



- Call the Control Room at **05.56.38.55.10**
- Remove contaminated clothing.
- Rinse the affected area with water.
- Inform site personnel and seek medical attention.



IN CASE OF AN ACCIDENTAL SPILL

If the spilled quantity is small, dilute it with plenty of water.



NO SMOKING OR VAPING



MORE INFORMATIONS
MOP, FDS, FSU...
Scan me!

